

# bow packing instructions



1. Here is what the cardboard box looks like on inside. The foam cushioning fits snugly inside the box and will not move. The TUBE should slide-in and out easily through the openings.
2. Inside the TUBE you will find a wooden holder with stamped images of bow frog and tip. Hang the bow on the pin so the frog and tip of the bow are aligned with the images on the holder. Secure with provided elastic band. Repeat with the second bow if needed on the reverse side of the holder.
3. Place the bow inside provided plastic sleeve and carefully insert the holder with the attached bow into the TUBE tip down and close the tube. The cap will go on and off easily but will stay on securely
4. Slide the TUBE into the box from the top and tape the box. Attach the shipping label which came with the TUBE. If you lost the shipping label you can download one from MyBowExpress.com Home page. Ship it USPS Priority or any service you like which provides tracking. We will let you know when we get your bow.
5. **Important!** When you get the package back please be careful with the box because you are going to need it for at least next shipping. Open from the TOP only. We expect that outer box will need to be replaced after one or two round trips and we will do it when indicated.

